

# FleXinspect Guide to Container Inspection



**FleXinspect T** with all available options    **FleXinspect M** with all available options    **FleXinspect BC** with all available options    **FleXinspect B** with all available options    **FleXinspect C** with all available options

## Finish Defects

Bent or Crooked Finish				
Blisters				
Broken Finish				
Bulged Finish				
Checked Finish				
Chipped Finish				
Corkage Check				
Crizzled Finish				
Dirty or Rough Finish				
Lineover				
Neck Ring Seam				
Offset Finish				
Overpress/Wire Edge				
Saddle Finish				
Seeds				
Split Finish				
Stones				
Tear or Under Ring Check				
Unfilled or Dip Finish				

## Neck Defects

Bent Neck				
Choked Neck or Bore				
Danny Neck or Neck Tear				
Dirty Neck				
Long Neck				
Pinched Neck				
Stuck Glass Particles				

## Shoulder Defects

Shoulder Check				
Sunken Shoulders				
Thin Shoulder				

## Sidewall & Body Defects

Bird Cage (Bird Swing)				
Black Spots				
Blank and Blow Mold Seam				
Blisters				
Body Checks				
Body Dimension				
Brush Marks				
Bulged Sides				
Cold Mold				
Dirty Ware				
Drag Marks				
Freaks				
Hot or Panel Checks				
Lap Marks or Wrinkles				
Letter Checks				
Loading Marks				
Oil Marks				
Pressure Checks				
Seeds				
Sidewall Stress				
Spikes				
Stones				
Stuck Glass Particles				
Sunken Sides				
Swab Ware				
Thin Ware				
Washboard				

## Base Defects

Baffle Marks				
Base Check				
Base Leaner				
Base Spikes				
Base Stress				
Black Spots				
Blisters				
Dirty Ware				
Oil Marks				
Seeds				
Stones				
Stuck Glass Particles or Tramp Glass				
Swab Ware				
Swung Baffle				

## Other Defects

Broken Ware				
Horizontal Tear				
Out-Of-Shape Ware (Leaner)				
Over-Max Height				
Shear Marks				
Under-Min Height				
Uneven or Bad Distribution				
Vertical Tear				
Stuck Ware				